

# Quick Change Tool Holder Locking Fixture



## Tool Holder Socket is Changeable

Easy to assemble and disassemble tool holder socket from and main body by just pressing the red button on the right hand side of the main body.



## Tool Holder Socket is Adjustable up to 360°

Easy to adjust tool holder for up to 360° (45° for each adjustment) while pressing down the large red button on the top of tool holder main body.



4 pcs of M10x40mm bolt will be fastened from the top of base plate of tool holder socket or 4 pcs of M12 bolt to be fastened from the bottom of the base plate of the tool holder main body.

### Main Body

ORDER NO.	MODEL NO.
425-TCP150	TCP-150



### Tool Holder Sockets

ORDER NO.	MODEL NO.
425-B30	BT30
425-B40	BT40
425-B50	BT50
425-C40	CT40
425-C50	CT50
425-H40	HSK40A
425-H63	HSK63A
425-H80	HSK80A
425-H100	HSK100A
425-H25E	HSK25E
425-H32E	HSK32E
425-H40E	HSK40E
425-H50E	HSK50E
425-H63F	HSK63F

